

Combat Net Radio Bearer Protocols (MIL-STD-188-220)

Table of Contents

Chapter 1 - Introduction

- MIL-STD-188-220
- COMBAT NET RADIO (CNR)
- BASIC PRINCIPLES
- TYPES OF SERVICE
 - Speed of Service (SOS)
 - Speed of Recovery (SOR)
 - Reliability
- MIL-STD-188-220 Data Frame

Chapter 2 - OSI7 Layer Model

- MIL-STD-188-220 & INTERNATIONAL COMMERCIAL STANDARDS
- OSI 7 LAYER MODEL
- DATA FRAME COMPILATION

Chapter 3 - Physical Layer

- INTRODUCTION
- COMSEC
 - Embedded COMSEC
 - External (Traditional) COMSEC
 - Not Used
- TRANSMISSION MODES
 - Synchronous Mode
 - Asynchronous Mode
 - Packet Mode
- TRANSMISSION FRAME
 - External COMSEC
 - Embedded COMSEC
 - COMSEC Compatibility
 - No COMSEC
 - Transmission Synchronisation
- ROBUST COMMUNICATIONS PROTOCOL (RCP)
- FEC & TDC
- NET BUSY INDICATION
- PRIMITIVES
 - Physical Layer Unitdata Request
 - Physical Layer Unitdata Indication
 - Physical Layer Status Indication
- MODEM/RADIO MODULATION SCHEMES
- PHYSICAL LAYER CONCATENATION

Chapter 4 - Data Link Layer – Transmission

- Header**
- INTRODUCTION
 - Transmission Header

Chapter 5 - Data Link Layer – Frames

- DATA LINK LAYER FRAMES
 - Unnumbered Frames (U PDUs)
 - Information Frames (I PDUs) 7
 - Supervisory Frames (S PDUs)
- DATA LINK LAYER FRAME COMPOSITION
 - Flag
 - Address
 - Reserved
 - Special Address
 - Unicast
 - Multicast One Hop
 - Group Multicast
 - Global Group Multicast
 - Address Format
 - Single Octet Addressing
 - 4 Octet Addressing
 - 6 Octet Addressing
 - Use of Multi-Formatted Address Fields
- CONTROL FIELD
 - Control Field Bit Legend
- INFORMATION FIELD
- FRAME CHECK SEQUENCE
- DATA LINK PDU CONSTRUCTION
- DATA LINK CONCATENATION
- PRIMITIVES
 - DL-Unitdata Request
 - DL-Unitdata Indication
 - DL-Status Indication
 - DL-Maximum Data Link Transmission Unit (MDLTU) Indication
 - DL-Address Indication
 - DL-Error Indication

Chapter 6 - Data Link Layer – Types Of Service

- TYPES OF SERVICE
 - Connection Orientated
 - Connectionless
 - Acknowledged Connectionless
- TYPE OF SERVICE 1
 - Unnumbered Information (UI) Command
 - Unnumbered Receive Ready (URR) Command
 - Unnumbered Receive Not Ready (URNR) Command
 - Topology Update ID Indication
 - Version CANTPRO Indication
 - TEST Command & Response

Flow Control
 TYPE OF SERVICE 2
 Asynchronous Balanced Mode
 Asynchronous Disconnect Mode
 Sequence Numbers
 Control Field P/F-bit
 TOS 2 U PDUs
 Set Asynchronous Balanced Mode Extended (SABME) Command (Data Link Connection Phase)
 Disconnect Command (Data Link Disconnection Phase)
 System Recovery – Reset Command
 Unnumbered Acknowledgement (UA) Response
 Frame Reject Response
 Disconnect Mode Response
 TOS 2 I PDUs
 TOS 2 S PDUs
 TOS 2 Flow Control
 TYPE OF SERVICE 3
 TOS 3 U Frames
 TOS 3 Information Exchange and Acknowledgements
 Immediate Retransmission
 TOS 3 Flow Control
 TYPE OF SERVICE 4
 TOS 4 U Frames
 TOS 4 S Frames
 Decoupled Receive Ready (DRR) Command
 DRR Response
 Decoupled Receive Not Ready (DRNR) Command
 DRNR Response
 TOS 4 Information Exchange and Acknowledgements
 TOS 4 Flow Control
 DUPLICATE FRAME DETECTION
 STATION CLASS
 WHICH TOS?
 QUIET MODE

Chapter 7 - Data Link Layer – Network Access

Delay

NETWORK ACCESS DELAY
 Network Busy Sensing
 Response Hold Delay (RHD)
 Timeout Period (TP)
 TP - Immediate Retransmission
 Network Access Delay (NAD)
 Random NAD (R-NAD) (Probabilistic)

Hybrid NAD (H-NAD) (Probabilistic)
 Radio Embedded NAD (RE-NAD) (Probabilistic)
 Prioritised NAD (P-NAD) (Deterministic)
 Deterministic Adaptable Priority NAD (DAP-NAD) (Deterministic)
 Data and Voice NAD (DAV-NAD) (Deterministic)
 Frequency of Access Ranking (FOAR)
 Initial Condition State

Chapter 8 - Timing & Associated Parameters

INTRODUCTION

Equipment Preamble Time (EPRE)
 Phasing Transmission Time (PHASING)
 Data Transmission Time (DATA)
 Coupled Ack Transmission Time (S)
 Equipment Lag Time (ELAG)
 Turnaround Time (TURN)
 DTE Ack Preparation Time (DTEACK)
 DTE Processing Time (DTEPROC)
 DTE Turnaround Time (DTETURN)
 Tolerance Time (TOL)
 Maximum Transmit Time (MTT)

Chapter 9 - Exchange Network Parameters

EXCHANGE NETWORK PARAMETERS (XNP)

Network Control Station (NCS)
 XNP Messages
 Join Request
 Join Accept
 Join Reject
 Hello
 Goodbye
 Parameter Update Request
 Parameter Update Message
 Status Notification Message
 NCS Handover
 NCS Handover Request
 NCS Accept/Reject
 NCS Election
 Participant Information Request
 Participant Information
 CANTPRO Indication
 Participant States
 Un-Joined State
 Joining State
 Joined State

Chapter 10 - Network Layer

INTRODUCTION

Intranet Header

Source Directed Relay Address Processing

TOPOLOGY UPDATE

Routing Tree

PRIMITIVES

INTERNET PROTOCOL (IP)

Subnetwork Dependent Convergence

Function (SNDCF)

N-Layer Pass-Through

Chapter 11 - Transport Layer

INTRODUCTION

Transmission Control Protocol (TCP)

User Datagram Protocol (UDP)

Segmentation Reassembly (S/R)

Chapter 12 - Hardware

INTRODUCTION

MIL-STD-188-220 COMPLIANT RADIO TYPES

SINGGARS ICOM CNR

SINGGARS System Improvement

Programme (SIP) CNR

SINGGARS ASIP/Advanced Data Radio (ADR)
CNR

UHF - Single Frequency and HAVEQUICK II

SATCOM

MIL-STD-188-220 Data Modems

Internet Controller (INC)

The Improved Data Modem (IDM)

Tadiran Tacter Terminals

LIST OF ACRONYMS

INDEX